



# **Poly Sync 40 Series**

## Bluetooth Speakerphone

User Guide


# Contents

|   |    |
|---|----|
| First-time setup                          | 3  |
| Controls                                  | 4  |
| LEDs                                      | 5  |
| Be safe                                   | 5  |
| USB Bluetooth adapter                     | 5  |
| Setup                                     | 7  |
| Corded setup                              | 7  |
| Mobile setup                              | 7  |
| USB adapter setup (adapter models only)   | 8  |
| Configure USB adapter                     | 9  |
| Charge                                    | 10 |
| Check battery status                      | 10 |
| Charge                                    | 10 |
| Charge your mobile phone                  | 10 |
| Load software                             | 11 |
| Update firmware                           | 11 |
| Daily Use                                 | 12 |
| Power                                     | 12 |
| Answer or end a call                      | 12 |
| Mute/Unmute                               | 12 |
| Volume                                    | 12 |
| Voice assistant (smartphone feature)      | 12 |
| Microsoft Teams button (Teams model only) | 12 |
| Customize your speakerphone               | 12 |
| Link speakerphones (daisy chain audio)    | 13 |
| Linked speakerphone audio settings        | 13 |
| Troubleshoot                              | 14 |
| What's in the box                         | 15 |
| Support                                   | 16 |

# First-time setup

**Important:** Your speakerphone is shipped from the factory in a Deepsleep mode to conserve battery. Activate your speakerphone by connecting the USB cable to a power source before first use.


- 1 Connect speakerphone USB cable to a wall charger or computer. When your speakerphone is activated, the LED bar lights up.



- 2 Connect or pair your speakerphone to take calls or stream media.

# Controls

A portable speakerphone with mobile and corded connectivity.



|                        |   |
|------------------------|---|
| ⌘                      | Bluetooth pairing   |
| 👤                      | Press to interact with Microsoft Teams (Teams model only, desktop application required)   |
| 🔊-                     | Volume down   |
| 🔇                      | Mute/unmute   |
| 🔊+                     | Volume up   |
| ☎️                     | Call  |
| Siri, Google Assistant | Default voice assistant (mobile feature)  |
| 🔌                      | Power on/off  |
| 🔌                      | USB phone charge port   |
| 🔗                      | Link 2 speakerphones (mobile feature)   |
| 🚀                      | Play/pause media (default). Customize feature in Poly Lens Desktop App<br><b>NOTE</b> Play/pause feature may not function with web-based apps |

## LEDs


| LED bar                | What lights mean                 |
|------------------------|----------------------------------|
| Crossing blue pattern  | Pairing mode                     |
| Solid blue             | Pairing successful (connected)   |
| Flashing green         | Incoming call                    |
| Solid green            | In a call                        |
| Solid red              | Mute active                      |
| Crossing white pattern | Linking mode (daisy chain audio) |
| 2 white blinks         | Linking successful               |

**NOTE** LEDs do not illuminate in standby mode.

## Be safe

Please read the safety guide for important safety, charging, battery and regulatory information before using your new speakerphone.

## USB Bluetooth adapter



Your high-fidelity Bluetooth USB adapter comes pre-paired to your Poly device. Plug it into your computer to connect to high-fidelity computer audio.

**NOTE** Adapter's USB connection and design may vary, but function is the same.

## Standard LEDs

| USB LEDs              | What they mean                |
|-----------------------|-------------------------------|
| Flashing red and blue | Pairing                       |
| Solid blue            | Device connected              |
| Flashing blue         | On a call                     |
| Solid red             | Mute active                   |
| Flashing purple       | Streaming media from computer |

---

**LEDs when Microsoft Teams\* is detected**

---

| <b>USB LEDs</b>       | <b>What they mean</b>        |
|-----------------------|------------------------------|
| Flashing red and blue | Pairing                      |
| Solid purple          | Microsoft Teams connected    |
| Flashing blue         | On a call                    |
| Solid red             | Mute active                  |
| Pulsing purple        | Microsoft Teams notification |


---

**NOTE** *\*Requires Microsoft Teams desktop application.*

# Setup


## Corded setup


Connect the USB cable from the speakerphone to the USB port on your computer.



**NOTE** In corded mode, the speakerphone powers on without using the Power button.

## Mobile setup

- 1 With your speakerphone powered on, press the Bluetooth  button for 2 seconds. You hear "pairing" and the LED flashes a crossing blue pattern.




- 2 Activate Bluetooth on your mobile device and set it to search new devices. Select "Poly Sync 40."
- 3 Pairing is successful when you hear "pairing successful" and the LED flashes blue.


## Secure Connection (mobile)

The Secure Connection feature provides extra security for Bluetooth calls in a conference room.

When enabled, your paired device disconnects after each mobile call, ensuring that device audio does not play through the speakerphone when not intended. Manage in Poly Lens Desktop App.

**NOTE** Enabling Secure Connection disconnects previously paired devices.

- 1 With your speakerphone powered on and Secure Connection enabled in Poly Lens Desktop App, press the Bluetooth  button for 2 seconds. You hear "pairing" and the LED flashes a crossing blue pattern.
- 2 Activate Bluetooth on your device and set it to search new devices. Select "Poly Sync 40."



- 3 Pairing is successful when you hear "pairing successful" and the LED flashes blue.




- 4 Make or take a mobile call or play music via Bluetooth.
- 5 After the end of a call, continue the mobile connection by pressing any button within 30 seconds. When no action is taken, the mobile connection ends and the Bluetooth button is no longer illuminated.

### USB adapter setup (adapter models only)

Your Bluetooth USB adapter comes pre-paired to your speakerphone.

- 1 Power on your speakerphone and insert the Bluetooth USB adapter into your computer.



- 2 The USB adapter LED flashes and then turns solid to indicate the speakerphone is connected to the USB adapter. You hear "PC connected" to indicate the connection has been established. When on a call, the LED on the USB adapter flashes blue. When not on a call the LED is solid.


**NOTE** Adapter design may vary.

- 3 Load Poly Lens Desktop App by visiting [poly.com/lens](http://poly.com/lens). This allows you to customize your headset behavior through advanced settings and options.

### Pair USB adapter again

Your USB adapter is pre-paired to your speakerphone. In the event that your adapter is disconnected or if bought separately, manually pair the adapter to your speakerphone.

- 1 Insert the Bluetooth USB adapter into your laptop or computer and wait for your computer to recognize it.
- 2 Put your speakerphone in pair mode by pressing the Bluetooth button for 2 seconds. You hear "pairing" and the LED bar flashes a blue crossing pattern.
- 3 Put your adapter into pair mode by pressing and holding the recessed pair button with a pen or paperclip until the adapter flashes red and blue.





**NOTE** Adapter design may vary

Pairing is successful when you hear "pairing successful; PC connected" and the adapter LED turns solid.

### Configure USB adapter

Your high-fidelity Bluetooth USB adapter comes ready to take calls. If you want to listen to music, you will need to configure your Bluetooth USB adapter.

#### Windows

- To configure your Bluetooth USB adapter to play music, go to Start menu > Control Panel > Sound > Playback tab. Select **Plantronics BT600**, set it as the Default Device and click OK.
- To pause music when you place or receive calls, go to Start menu > Control Panel > Sound > Communications tab and select the desired parameter.

#### Mac

- To configure the Bluetooth USB adapter, go to Apple menu > System Preferences > Sound. On both the Input and Output tabs, select **Plantronics BT600**.

# Charge

## Check battery status

To check battery status:

- With speakerphone inactive, tap the Power button to hear battery status
- With speakerphone inactive, tap any button to view the LED bar

## Battery status LEDs

| LED bar                | Battery status   |
|------------------------|------------------|
| Solid white long bar   | Battery full     |
| Solid white medium bar | Battery high     |
| Solid white short bar  | Battery medium   |
| Solid red              | Battery low      |
| Red flashes            | Battery critical |


**NOTE** LEDs do not illuminate in standby mode.

## Charge

Charge the speakerphone via USB using your computer or a wall charger (not provided). The LED bar pulses while charging and turns solid white when fully charged. Allow 5 hours for a full charge.


**NOTE** For faster charging, connect to a wall charger or to your computer's quick-charge USB port, if available.

**NOTE** Your speakerphone has a combined USB-A and USB-C cable for easy connection to either type of port.



## Charge your mobile phone

With the speakerphone powered on, charge your phone by connecting your phone's charge cable to the speakerphone USB-A port (cable not provided).



**NOTE** Speakerphone battery level must be medium or higher.

**NOTE** Connection provides power only.

# Load software

Customize your device behavior through advanced settings and options with Poly Lens Desktop App. Some softphones require the installation of Poly software to enable device call control (answer/end and mute) functionality. Download: [poly.com/lens](https://poly.com/lens).

**NOTE** *Device settings are also available in Plantronics Hub Desktop App.*

## Update firmware







Keep your firmware up-to-date to improve performance and add new features to your Poly device.

Update your firmware using your computer with Poly Lens App. Download at [poly.com/lens](https://poly.com/lens).

While updating firmware:

- Do not use your Poly device until the update is complete.
- Disconnect your Poly device from paired devices such as phones, tablets and computers.
- Do not start a second update from a second device.
- Do not stream media.
- Do not answer or place a call.

# Daily Use


|  |   |
|--|---|
| <b>Power</b>                                     | Press the Power  button for 2 seconds to power on or off. The LED bar illuminates when powered on.   |
| <b>Answer or end a call</b>                      | Press the Call  button to answer or end a call.  |
| <b>Mute/Unmute</b>                               | During an active call, press the Mute  button to mute or unmute the microphones. Manage mute settings in Poly Lens Desktop App.  |
| <b>Volume</b>                                    | Press the Volume up (+) or down (-) buttons to increase or decrease volume.<br><br><b>Adjust speakerphone microphone volume</b><br>Place a test softphone call and adjust softphone volume and PC sound volume accordingly.   |
| <b>Voice assistant (smartphone feature)</b>      | <b>Siri, Google Assistant, Cortana</b> Press and hold the Call button for 2 seconds to activate your phone's default voice assistant. Wait for the phone prompt to activate voice dialing, search, and other smartphone voice controls.   |
| <b>Microsoft Teams button (Teams model only)</b> | Press the Teams  button to interact with Microsoft Teams when not on a call.<br><b>NOTE</b> <i>Not supported for mobile use.</i><br><br><b>NOTE</b> <i>The Microsoft Teams application must be installed.</i>  |
| <b>Customize your speakerphone</b>               | Customize your Rocket  button feature in Poly Lens Desktop App. Play/pause media is the default feature when you tap the Rocket  button.<br><br><b>Choose from:</b> <ul style="list-style-type: none"><li>• Play/pause audio (default)</li><li>• Device status check</li><li>• Clear trusted device list</li><li>• <b>Mobile calls only:</b> Default voice assistant (Siri, Google Assistant)</li><li>• Redial</li><li>• Hold/resume call (varies by softphone)</li></ul> |


# Link speakerphones (daisy chain audio)

Use two Poly Sync speakerphones with your Bluetooth-paired mobile device.


**IMPORTANT** Linking mode is available with Bluetooth mobile device connection only. This feature is not available when your speakerphone is connected to a computer with USB cable.


**NOTE** Linking mode can be entered when both speakerphones are inactive (not in a call or streaming media).

- 1 Power on both speakerphones.
- 2 Ensure that the speakerphones are unplugged from any computer.
- 3 Wirelessly link by pressing both Link  buttons for 2 seconds. You hear "connecting" and the LEDs pulse white.  
Linking is successful when you hear "connection successful" and the LED flashes white on both speakerphones.



- 4 Pair one speakerphone to your idle mobile device.  
You hear "phone connected" when successfully paired.  
**NOTE** You may pair your mobile device before or after linking speakerphones.



- 5 Control the system from either speakerphone to play audio or make calls.
- 6 End linking mode by pressing both Link  buttons for 2 seconds.  
You hear "device disconnected."

Linked speakerphone  
audio settings

Manage daisy chain audio settings in Poly Lens Desktop App.

# Troubleshoot

---

When I attempt to use my speakerphone for the first time, it does not power on.

Your speakerphone is shipped from the factory in a DeepSleep mode to conserve battery. Activate your speakerphone by connecting the USB cable to a power source before first use.


---

My speakerphone doesn't charge as quickly as expected.

For faster charging, connect the USB cable to a wall charger or to your computer's quick-charge USB port, if available.


---


**(Teams model only)** How do I interact with Microsoft Teams?

- Tap the Teams  button to quickly open and use Microsoft Teams.
  - Teams model is compatible with Microsoft Teams desktop app. Teams mobile app is not supported.
- 

How do I use the Secure Connection feature with my mobile phone?


- The Secure Connection feature provides extra security for Bluetooth calls in a conference room.
- Activate feature in Poly Lens Desktop App.
  - Automatically disconnects speakerphone from paired mobile device after a call.
  - Continue the mobile connection by pressing any button within 30 seconds after the end of a call.
- 

How do I customize the Rocket  button feature?


- Ensure Poly Lens Desktop App is loaded on your computer.
  - Customize your Rocket  button feature in Poly Lens Desktop App.
  - Play/pause media feature is default feature on your speakerphone.
-

# What's in the box


Contents may vary by product.



Speakerphone with combined USB-A and USB-C cable



Bluetooth USB Adapter (Poly Sync 40+ only; Design may vary)



Quick start guide

# Support

## NEED MORE HELP?

[poly.com/support](https://poly.com/support)

**Manufacturer:**

**Plantronics, Inc.**

345 Encinal Street  
Santa Cruz, CA 95060  
United States

**Plantronics B.V.**

Scorpius 171  
2132 LR Hoofddorp  
Netherlands

**Plantronics Ltd.**

Building 4, Foundation Park  
Cannon Lane, Part 1st Floor  
Maidenhead, SL6 3UD  
United Kingdom

© 2021 Plantronics, Inc. All rights reserved. Poly, the propeller design, and the Poly logo are trademarks of Plantronics, Inc. Bluetooth is a registered trademark of Bluetooth SIG, Inc. and any use by Plantronics, Inc. is under license. All other trademarks are the property of their respective owners. Manufactured by Plantronics, Inc.

Model ID: SY40/SY40-M (may be followed by /BT600). System: Poly Sync 40 has a SY40/SY40-M speakerphone. Poly Sync 40+ has a SY40/SY40-M speakerphone and a BT600 adapter.

218940-06 10.21